
Swing Check Valve







L	

Dimensions are in "milimeter"

TECHNICAL DATA SHEET			
Product Name	Swing Check Valve		
Standard	TSEK		
Working Temperature	-30°C / +90°C		
Pressure Class	PN 16		
Intended Use	Industrial Application		

MATERIALS				
Body	Brass (CW617N)/(CW614N)			
Cover	Brass (CW617N)/(CW614N)			
Gate	Brass (CW617N)/(CW614N)			
Gate Gasket	NBR / EPDM			
Rod	Brass (CW617N)/(CW614N)			

µm: Micrometer

	ENICI	UNIC	∼t ou	82 4
IJIIVI	CIA'2I	C.VIU	ui ou	0/4

Code	60	61	62	63	64	65	66	67
DN	15	20	25	32	40	50	65	80
D1 (thread)	1/2"	3/4"	1"	1 1/4"	1 1/2"	2"	2 1/2"	3"
D2 (thread)	1/2"	3/4"	1"	1 1/4"	1 1/2"	2"	2 1/2"	3"
AA	25	30	38	47	54	65	83	97
ø	34,6	42	45	58,6	66,5	79,4	101	117,4
L	49,5	50,6	59	62,2	68,6	72,6	93	103

INSTALLATION and OPERATING INSTRUCTION

- 1- Make sure there is no damage on the product may occur during transport and shipping. Before assembly do not unpack the product in order to prevent from the external effects.
- 2- Clean all kinds of contaminants before assembly.
- 3- Make sure that the thread length to be connected to the valve is not too short or too long than the thread length of the valve.
- 4- Install the valve with the appropriate tool from the side where you'll mount it.
- 5- Use enough flax or plumping adhesive.
- 6- Do not paint the valve, do not expose the valve with abrasive chemicals,
- 7- While installation, pay attention to arrow direction.